

SimplicitySlate Quick Start Guide

NiMH Rechargeable Batteries

The tablet ships with pre-charged NiMH rechargeable batteries (2xAA). These provide many hours of use between charges.

USB Receiver

The USB receiver is stored in the battery compartment.



USB Plug (for wired power)

The tablet can be used even when the batteries are drained by plugging the tablet into a USB port on your computer.

Active/Write Status LED

The blue LED will flash when the tablet is actively communicating with the computer and ready to be used.

Sleep/Settings Button

The tablet will go into sleep mode after several minutes of inactivity. Press this button to wake up the tablet. Also use this button to connect the tablet to the USB receiver.

Low Battery LED

The red LED will light when battery power is too low to use the tablet.

Power Switch

Pen

Use the pen as a pointing device by writing with it over the active area of the tablet.

Upper Pen Switch

Windows Vista - Left Click (press)
Windows 7 - Left Click (press)
Windows 8 - N/A
Mac OS X - N/A

Lower Pen Switch

Windows Vista - N/A
Windows 7 - Right Click (press & tap)
Windows 8 - Right Click (press & tap)
Mac OS X - Right Click (press)

Pen Nib

All Operating Systems: Tap to click, Double Tap to Double Click, Tap and drag to move.

Windows Vista/7/8: Hold down pen to bring up right click menu.

Windows 8.1 and Mac OS X: Holding down pen tip will not bring up right click (use lower pen button instead - press button then tap pen)

USING TABLET FOR FIRST TIME

1. Plug USB Receiver into Computer.

The drivers for the tablet will be installed automatically. Just wait 15-45 seconds for installation to complete.



2. Insert the NiMH batteries.

The batteries are pre-charged and ready to use.

3. Hold Down the Settings Button

Press the Setting Button and keep holding down the button while you switch on the tablet power..




4. Switch on the Tablet.

Turn on the power switch and the tablet will connect to the USB Receiver and your computer. The ACTIVE/WRITE LED will start to blink blue.

5. Install Annotation Software

You can use your tablet now without installing any additional software. For maximum performance, however, we recommend installing XPress annotation software. (see back of QuickStart Guide)



Active Writing Surface

Using the pen on the active area will allow for wireless control of your computer's pointer.

Media Shortcuts

Tap the media shortcuts with the pen tip to easily, scroll, adjust volume (Windows OS only) play, stop or skip audio or video tracks, and more.

SUPPORT: 718-392-5380 x2 // support@recordexusa.com

recordex™

XPress Annotation Suite

for Windows™ operating system

Your SimplicitySlate includes a free copy of our exclusive XPress Annotation software. The all new XPress Annotation Suite works with the SimplicitySlate wireless tablet to provide a powerful on-screen annotation toolbar set that can be used in glass mode to annotate over your computer desktop (i.e. web pages, documents, photos, presentation slides, etc.)

The toolbar also allows for easy switching between whiteboard and blackboard modes. In these modes you can create an unlimited number of white or black slides and annotate over them then save or print them. Other powerful features such as spotlight, screen shading (hide part of screen) and magnifying glass are included on the toolbar for simple tap and use operation.

In addition we have built in support for document cameras right within the XPress software. Simply click the XSight Camera tool and you are able to add a live video feed from nearly any installed USB Video Device. Just a few clicks and you've integrated live video into your whiteboard, blackboard or transparent page. Capture stills from the camera or record video and instantly embed them into your annotation page. It couldn't be simpler.

NOTE: XPress is currently only available for Windows users. However, we are in process of making an OS X version and hope to have one available soon. Please check our website for the most up to date information.

For Mac™ OS X™ users we recommend RM Easiteach NextGen for Mac. Or you can check out the Apple AppStore for other whiteboard software options.

Step 1: Download The App

<http://www.recordexusa.com/xpress-download.html>

Step 2: Install Application


Run the "XPress.msi" downloaded in step 1.

Note: Depending on the setup of your computer you may need to be logged in as an administrator to install the application.

Step 3: Make sure the SimplicitySlate USB receiver is plugged in to your computer and then launch the application.

Note: As long as you SimplicitySlate receiver is plugged into your computer you will not need a license code to activate the software. The software will activate automatically when the SimplicitySlate hardware is detected.

XPress toolbars.



Need Help?

**Go to www.recordexusa.com/xpress-help.html
or contact us at support@recordexusa.com.**

We're happy to help!